

UNIVERSAL A/C REMOTE CONTROL













SETTING OF THE REMOTE CONTROL

The remote control can be set to 3 different modes. Choose mode A if the brand of your air conditioner is among those in the image below, or modes B or C for all other brands.

A) Point-to-point quick search (only for major brands)

1. Aim the remote control towards the air conditioner receiver window.
2. Press and hold the appropriate code button corresponding to your A/C brand (for example ▲ button for LG and Samsung brand) until the air conditioner turns on and you hear a 'beep' sound; release the button and the setting is completed.
3. Check the button functions. If the buttons work correctly, the code setting is effective. If not, please repeat steps 2 and 3.

Brand Code Button Table

 HEAT	 COOL	 E.A.Heating	 A
CHIGO/TCL	MIDEA CHANGHONG	FRESTECH YAIR	HISENSE KELON
 B	 C	 TEMP	 TEMP
CHUNLAN AUX	HAIER MITSUBISHI	LG SAMSUNG	SHINCO AUCMA
 FAN	 MODE	 Manual Wind	 Auto Wind
DAIKIN CARRIER	GREE HUALING	HITACHI PANASONIC	SHARP SANYO

B) Manual Code Input

1. Connected to www.wellclima.com website, find air conditioner brand in the 'CODE LIST' of PLUS model and check the first set of codes.
 2. Press and hold **SET** button, then press **POWER** button and hold them down. Release the two buttons when the model code '---' flashes on the screen window. Press 'TEMP▲' or 'TEMP▼' until the code found in Step 1 appears on the screen window (you can keep the **TEMP** keys pressed to scroll the codes faster).
 3. Press the SET button to exit, check the button functions. If the device respond correctly the setting is finished, if not, please repeat steps 2 and 3 with next set of codes.
- LOOK OUT:** when the codes are separated by a - sign it means all the numbers between the first and the last (es LG 600-609 you have to test codes 600, 601, 602.....>609). If none of the codes work with your air conditioner or if your brand is not in the list don't worry, proceed with the Automatic Code Search


C) Automatic Code Search for applicable model

1. Aim the remote towards the air conditioner receiver window.
2. Press and hold SET button, about 6 seconds later the model code '---' starts to flash, do not release the button until the air conditioner switches on automatically.
3. Release the SET button immediately when the conditioner turns on and check the button functions. If the buttons work correctly, the code setting is effective. If not, please repeat steps 2 and 3.
4. A complete scan of all codes takes about 30 minutes. Do not stop the search before, or before the air conditioner switches on.

RESTORE TO FACTORY SETTING

Press and hold SET button and then press **FAN**  button and hold them down about 3 seconds to restore the factory settings.

REMOTE CONTROL FUNCTIONS



1. Fast cool/heat function

Press the “COOL” button: The air conditioner will be set to cooling mode: **21°C**, strong wind, auto wind direction. Press the “HEAT” button: the air conditioner will be set to heating mode: **27°C**, strong wind, auto wind direction.

* In the heating mode, press the **E.A.HEAT**  button to start the electrical assistant heating function. Only applicable for certain models.

2. Timer ON-OFF

The remote control is equipped with the timer function of the original AC remote. Press the **TIME ON** or **TIME OFF** buttons (one press for one hour), the air conditioner timer light will switch on. This means that the air conditioner timer function is now operational.

* **This function requires the air conditioner to have the timer function, or else this button will not work.**

3. Child-lock function

Lock: Keep pressed **SET** and then **M.SWING**  buttons. The screen displays the Child Lock  icon.

Unlock: Keep pressed **SET** and then **M.SWING**  buttons. The **Child Lock**  icon disappears.

4. Clock function setting

A. Keep pressed the “SET” button and press “Mode” button.

B. Press the **TEMP▲** (or **TEMP▼**) button to increase (or decrease) by 1 hour.

C. Press the “SET” button to complete setting the hour. Now the minute digits flash.

Press the **TEMP▲** (**TEMP▼**) button to set the minutes.

D. After the minutes are set, press the “SET” button to exit clock setting.

5. Temperature measurement

Indoor temperature will be displayed after battery is fixed in; range of temperature measurement: 0-35 degree.

6. Fahrenheit function “C/F”

Press key “C/F” to switch between “Celsius” and “Fahrenheit”.

ANY PROBLEMS?

We thank you for purchasing a **w e l l c l i m a** product covered by a legal warranty.

This remote control is compatible with 99% of the air conditioners on the market. It can operate only if the air conditioner receiver works well. If you find any problems or remote control cannot be used appropriately, please visit HELP and FAQs page on our website **www.wellclima.com** or contact us and we will provide our best service for you.

• • • • •
In compliance with directive 2012/19/EU D.L. N°49/2014 Multiservizi (owner of wellclima brand) being the suppliers of this products issues the following information: it is mandatory not to dispose of the RAEE as if they were urban waste, but to carry out a separate collection of them.

When delivering the equipment upon purchase of a new one, the same manufacturer shall provide in reusing, recycling it or other forms of recycle through measures implemented and approved by the public administrations. Such information is supplied in order to prevent potential effects on the environment and human health due to the presence of dangerous substances in electronic equipments or due to an improper use of the same. Therefore every electronic equipment sold shall be subject to this directive and shall be marked with the symbol shown here below.

The brands and codes list is available on **www.wellclima.com**.

